



# Barcode scanner BC3100 2D

Guide de démarrage rapide

## Réinitialisation du scanner :



Code Programming ON



Load All Factory Default



Code Programming OFF

## Scanner tenu en main :



Code Programming ON



Hand-held Mode



Code Programming OFF

Interface USB :



Code Programming ON



Select USB HID-KBW



Code Programming OFF

Langue française :



Code Programming ON



Select Country Code



7



Save



Code Programming OFF

Suffixe Retour Charriot :



Code Programming ON



Enable All Prefix/Suffix



Disable AIM Prefix for All Barcodes



No Code ID Prefix



Code Programming OFF