Quick Start Guide

TP80

Packing List

Printer

USB Cable

Power Adapter

Power Cord

Roll Paper

Quick Start Guide

Serial Cable

CD

⚠Notes:

1. The packing materials depend on the order actually .
2. The power adapter and power cord vary by local or region.

Appearance

■ Front

■ Back

■ Inside

Paper Loading

1. Press the cover open button to open the top cover.

2. Install the roll paper in the correct direction of the roll paper.

3. Pull out some roll paper, and close the top cover.

4. Tear the extra paper of the printer.

Power Supply

1. Make sure the printer power is turned off.
2. Connect power adapter to printer.
3. Connect power adapter to power cord.
4. Plug the other side of power cord into the socket outlet.

Interface